# Acknowledged globally





### HY-EX-6

#### **Item Number** 4687047

Hydraulic expander for soft copper pipe and aluminum. With only a few pumping movements, a clean socket is achieved with one hand and little effort. For inch pipes from 3/8" to 1 1/8" diameter.

- With interchangeable and expandable heads
- Simple operation with only one hand for expanding and releasing
- Compact design for use in narrow places
- 120° angle for ergonomic use
- Compatible with other REFCO Expander tools
- Up to 10 expander heads available

#### **Technical Data**

Material	Stainless steel   Steel   Aluminium   Rubber	
Color	yellow   green   black	
Tube Diameter	6 - 42 mm	
Packaging	Sturdy plastic case	
Tube Material	Copper   Brass   Aluminum	
Tube Diameter 2	1/4 - 1 5/8 "	

### Accessories

4687344	HY-EX-1/4"	Spare head ø 1/4"
4687346	HY-EX-5/16"	Spare head ø 5/16"
4687345	HY-EX-1"	Spare head ø 1"
4687478	HY-EX-1 1/4"	Spare head ø 1 1/4"

# Acknowledged globally



4687347	HY-EX-1 3/8"	Spare head ø 1 3/8"
4687477	HY-EX-1 1/2"	Spare head ø 1 1/2"
4687348	HY-EX-1 5/8"	Spare head ø 1 5/8"
4687949	HY-EX-6MM	Spare head ø 6mm
4687441	HY-EX-8MM	Spare head ø 8mm
4687442	HY-EX-10MM	Spare head ø 10 mm
4687443	HY-EX-12MM	Spare head ø 12 mm
4687444	HY-EX-15MM	Spare head ø 15 mm
4687445	HY-EX-16MM	Spare head ø 16 mm
4687446	HY-EX-18MM	Spare head ø 18 mm
4687447	HY-EX-22MM	Spare head ø 22 mm
4687448	HY-EX-25MM	Spare head ø 25 mm
4687449	HY-EX-28MM	Spare head ø 28 mm
4687479	HY-EX-35MM	Spare head ø 35 mm
4687450	HY-EX-42MM	Spare head ø 42 mm
9883750	RFA-209-STYLO	Deburring tool
9881649	RFA-209	Inner-outer reamer

## **Spare Parts**

4687367	HY-EX-3/8"	Spare head ø 3/8"
4687366	HY-EX-1/2"	Spare head ø 1/2"
4687365	HY-EX-5/8"	Spare head ø 5/8"
4687368	HY-EX-3/4"	Spare head ø 3/4"
4687369	HY-EX-7/8"	Spare head ø 7/8"
4687370	HY-EX-1 1/8"	Spare head ø 1 1/8"
4687051	RFA-209-STYLO- HD	Deburring tool
4687579	HY-OIL	Hydraulic oil for HY-EX, 50ml
4687384	HY-EX-V	Spare latch for HY-EX case